



**OTG Support List**

Brand Name	Smartphone/Tablet	Model Name	Note
Acer	Tablet	Iconia A1-810	
		Iconia A1-811	
		Iconia A3-A10	
ASUS	Tablet	Nexus 7,Nexus 7 2	*App "Nexus Media Importer" required: Nexus 7,Nexus 7 2
	Smartphone	PadFone,PadFone 2,PadFone Infinity, The New PadFone Infinity	
	Tablet	Fonepad	*Fonepad need to update F/W to V3.2.2
		MeMO Pad 8 (ME180A)	
		MeMO Pad 10 (ME180A)	
MeMO Pad FHD 10 LTE MeMO Pad FHD 10 Transformer Pad TF700T,701T			
hTC	Smartphone	Desire 500,600,U,X, +, HTC J	
		Butterfly,Butterfly S	
		One,One X,One X+,One Dual, One mini, One Max,New One,One(M8)	*Android 4.1.1 required:One X, HTC J
Huawei	Smartphone	Ascend D2,Ascend P1,Ascend P6,Stream X GL07S(Japan)	
	Tablet	MediaPad 7 Youth,Vogue MediaPad 10 FHD	
Lenovo	Smartphone	Lenovo LePhone P770,Lenovo Vibe Z K910, Lenovo Vibe X S960	
	Tablet	IdeaTab A3000,IdeaTab A1000, IdeaTab S6000	
LG	Smartphone	Nexus 5 Optimus G Pro,GJ,G2,G Pro Lite,G Pro Lite Dual	
Motorola	Smartphone	RAZR M	
MSI	Tablet	Enjoy 7 Plus,10 Plus Primo 73,76,81,91	
NOKIA	Tablet	NOKIA Lumia 2520	
Samsung	Smartphone	Galaxy Ace,Ace 2,Ace 3	Needed USB Connection adapter : Galaxy Note 10.1, Galaxy Tab 7.0 Plus, Galaxy Tab 7.7 Plus, Galaxy Tab 8.9, Galaxy Tab 10.1, Galaxy Tab2 7.0, Galaxy Tab2 10.1
		Galaxy S2,S2 PLUS,S3,S4,S4 ZOOM,S4 LTE-A,S5	
		Galaxy Mega 6.3	
		Galaxy J,WIN	
		Galaxy Note,Note 2,Note 3,Note 3 LTE	
		Note 8.0,Note 2014 4G LTE	
	Tablet	Galaxy Tab3 7.0,Tab3 8.0,Tab3 10.1	
		Galaxy Tab2 7.0,Tab2 10.1	
		Galaxy Tab 7.0 Plus,Tab 7.7,Tab 10.1	
		Galaxy TabPRO 8.4 LTE Galaxy TabPRO 10.1	
SONY	Smartphone	Xperia C,,J,M	
		Xperia U,UL,V,VC,VL	
		Xperia Z,ZL,ZR,Z1,Z Ultra,Z2	
Tablet	Xperia Tablet S,Z		
Xiami	Smartphone	MI1S,MI2,MI2A,MI2S,MI3	
		Hongmi,Hongmi NOTE	
ZTE	Smartphone	U950,U985,V967S	

\*Please confirm your Smartphone or Tablet can support the USB OTG function

\*Some device need to download the app in Google Play to unlock OTG function